


TITEM	IOUT NOTIC	·	
BOTTLE FILLER, 1117/1119 HS MODELS	ITEM	DESCRIPTION	PART NO.
FRAME, MOUNTING, SINGLE, W/CORD, RIVIVE FTN & 2000HSA.8		BOTTLE FILLER, 1011 HS MODELS	HS4
4         FRAME, MOUNTING, DUAL, W/CORD, RIVIVE FTN MODELS         HS12           5         FILTER, 12XX EWC, LEAD/CYST/CTO         6428           6         STRAINER, MESH, 110 MICRON, NON-SERVICEABLE         6434           7         RELAY, POWER, SPDT, 10A, 240VAC SW, 12VDC COIL         0210001185           8         PANEL, LOWER, 304 SST, HI-LO CHILLED         0410000924           9         VALVE, SOLENOID, 3/8 QC, 120VAC         0110000827.4           10         DRAIN BASIN, HS MODELS         0410000894           11         GRATE, 304 SST, HS MODELS         0410000895           12         SCREW, 8-32 UNC X. 375, SST, PAN, T-20 TORX         0310000550           13         FUSE, 10A-250VAC, SLOW BLOW, 5MM X 20MM, GLASS         0210001120           14         PCBA, PROXIMITY SENSOR, HS MODELS         0210001175           15         AERATOR, LAMINAR FLOW CONTROL, 1.2 GPM         0110001537           16         AERATOR INSTALLATION TOOL         0510000672           17         CHILLER REMOTE 115V/60HZ         HCR8           18         RFID BOARD PCBA         0210000745.6           19         COVER, CORNER, HS MODELS         0410000897           20         CLIP, PANEL ATTACHMENT, HS MODELS         0410000893           21         SCREW, 8-32 UNC X. 56		BOTTLE FILLER, 1117/1119 HS MODELS	HS6
5         FILTER, 12XX EWC, LEAD/CYST/CTO         6428           6         STRAINER, MESH, 110 MICRON, NON-SERVICEABLE         6434           7         RELAY, POWER, SPDT, 10A, 240VAC SW, 12VDC COIL         0210001185           8         PANEL, LOWER, 304 SST, HI-LO CHILLED         0410000924           9         VALVE, SOLENOID, 3/8 QC, 120VAC         0110000827.4           10         DRAIN BASIN, HS MODELS         0410000894           11         GRATE, 304 SST, HS MODELS         0410000895           12         SCREW, 8-32 UNC X. 375, SST, PAN, T-20 TORX         0310000550           13         FUSE, 10A-250VAC, SLOW BLOW, 5MM X 20MM, GLASS         0210001120           14         PCBA, PROXIMITY SENSOR, HS MODELS         0210001175           15         AERATOR, LAMINAR FLOW CONTROL, 1.2 GPM         0110001537           16         AERATOR INSTALLATION TOOL         0510000672           17         CHILLER REMOTE 115V/60HZ         HCR8           18         RFID BOARD PCBA         0210000745.6           19         COVER, CORNER, HS MODELS         0410000897           20         CLIP, PANEL ATTACHMENT, HS MODELS         0410000897           21         SCREW, 8-32 UNC X. 563, SST, BUTTON HEAD, T20 TORX         0310000551           22         SCREW, 10-24		FRAME, MOUNTING, SINGLE, W/CORD, RIVIVE FTN & 2000HSA.8	HS11
6         STRAINER, MESH, 110 MICRON, NON-SERVICEABLE         6434           7         RELAY, POWER, SPDT, 10A, 240VAC SW, 12VDC COIL         0210001185           8         PANEL, LOWER, 304 SST, HI-LO CHILLED         0410000924           9         VALVE, SOLENOID, 3/8 QC, 120VAC         0110000827.4           10         DRAIN BASIN, HS MODELS         0410000894           11         GRATE, 304 SST, HS MODELS         0410000895           12         SCREW, 8-32 UNC X. 375, SST, PAN, T-20 TORX         0310000550           13         FUSE, 10A-250VAC, SLOW BLOW, 5MM X 20MM, GLASS         0210001120           14         PCBA, PROXIMITY SENSOR, HS MODELS         0210001175           15         AERATOR, LAMINAR FLOW CONTROL, 1.2 GPM         0110001537           16         AERATOR INSTALLATION TOOL         0510000672           17         CHILLER REMOTE 115V/60HZ         HCR8           18         RFID BOARD PCBA         0210000745.6           19         COVER, CORNER, HS MODELS         0410000897           20         CLIP, PANEL ATTACHMENT, HS MODELS         0410000897           21         SCREW, 8-32 UNC X. 563, SST, BUTTON HEAD, T20 TORX         0310000554           23         BUBBLER HEAD, PCP, 1001 BOWL         5705           24         BUBBLER HEAD,		FRAME, MOUNTING, DUAL, W/CORD, RIVIVE FTN MODELS	HS12
7         RELAY, POWER, SPDT, 10A, 240VAC SW, 12VDC COIL         0210001185           8         PANEL, LOWER, 304 SST, HI-LO CHILLED         0410000924           9         VALVE, SOLENOID, 3/8 QC, 120VAC         0110000827.4           10         DRAIN BASIN, HS MODELS         0410000894           11         GRATE, 304 SST, HS MODELS         0410000895           12         SCREW, 8-32 UNC X. 375, SST, PAN, T-20 TORX         0310000550           13         FUSE, 10A-250VAC, SLOW BLOW, 5MM X 20MM, GLASS         0210001120           14         PCBA, PROXIMITY SENSOR, HS MODELS         0210001175           15         AERATOR, LAMINAR FLOW CONTROL, 1.2 GPM         0110001537           16         AERATOR, INSTALLATION TOOL         0510000672           17         CHILLER REMOTE 115V/60HZ         HCR8           18         RFID BOARD PCBA         0210000745.6           19         COVER, CORNER, HS MODELS         0410000897           20         CLIP, PANEL ATTACHMENT, HS MODELS         0410000897           21         SCREW, 8-32 UNC X. 500, SST, PAN, T-20 TORX         0310000551           22         SCREW, 10-24 UNC X. 563, SST, BUTTON HEAD, T20 TORX         0310000540           23         BUBBLER HEAD, PCP, 1107 AND 1109 FTN         5705           24         <	5	FILTER, 12XX EWC, LEAD/CYST/CTO	6428
8         PANEL, LÓWER, 304 SST, HI-LO CHILLED         0410000924           9         VALVE, SOLENOID, 3/8 QC, 120VAC         0110000827.4           10         DRAIN BASIN, HS MODELS         0410000894           11         GRATE, 304 SST, HS MODELS         0410000895           12         SCREW, 8-32 UNC X. 375, SST, PAN, T-20 TORX         0310000550           13         FUSE, 10A-250VAC, SLOW BLOW, 5MM X 20MM, GLASS         0210001120           14         PCBA, PROXIMITY SENSOR, HS MODELS         0210001175           15         AERATOR, LAMINAR FLOW CONTROL, 1.2 GPM         0110001537           16         AERATOR INSTALLATION TOOL         0510000672           17         CHILLER REMOTE 115V/60HZ         HCR8           18         RFID BOARD PCBA         0210000745.6           19         COVER, CORNER, HS MODELS         0410000903           21         SCREW, CORNER, HS MODELS         0410000903           21         SCREW, 8-32 UNC X.500, SST, PAN, T-20 TORX         0310000551           22         SCREW, 4-32 UNC X.563, SST, BUTTON HEAD, T20 TORX         0310000540           23         BUBBLER HEAD, PCP, 1001 BOWL         5705           24         BUBBLER HEAD, PCP, 1107 AND 1109 FTN         5703M           25         BUTTON, PUSH, 5874, FLANGED		STRAINER, MESH, 110 MICRON, NON-SERVICEABLE	6434
9         VALVE, SOLENOID, 3/8 QC, 120VAC         0110000827.4           10         DRAIN BASIN, HS MODELS         0410000894           11         GRATE, 304 SST, HS MODELS         0410000895           12         SCREW, 8-32 UNC X. 375, SST, PAN, T-20 TORX         0310000550           13         FUSE, 10A-250VAC, SLOW BLOW, 5MM X 20MM, GLASS         0210001120           14         PCBA, PROXIMITY SENSOR, HS MODELS         0210001175           15         AERATOR, LAMINAR FLOW CONTROL, 1.2 GPM         0110001537           16         AERATOR INSTALLATION TOOL         0510000672           17         CHILLER REMOTE 115V/60HZ         HCR8           18         RFID BOARD PCBA         0210000745.6           19         COVER, CORNER, HS MODELS         0410000897           20         CLIP, PANEL ATTACHMENT, HS MODELS         0410000897           20         CLIP, PANEL ATTACHMENT, HS MODELS         0410000903           21         SCREW, 8-32 UNC X.500, SST, PAN, T-20 TORX         0310000551           22         SCREW, 10-24 UNC X.563, SST, BUTTON HEAD, T20 TORX         0310000551           23         BUBBLER HEAD, PCP, 1001 BOWL         5705           24         BUBBLER HEAD, PCP, 1107 AND 1109 FTN         5703M           25         BUTTON, PUSH, 5874, FLAN		RELAY, POWER, SPDT, 10A, 240VAC SW, 12VDC COIL	0210001185
10         DRAIN BASIN, HS MODELS         0410000894           11         GRATE, 304 SST, HS MODELS         0410000895           12         SCREW, 8-32 UNC X. 375, SST, PAN, T-20 TORX         0310000550           13         FUSE, 10A-250VAC, SLOW BLOW, 5MM X. 20MM, GLASS         0210001120           14         PCBA, PROXIMITY SENSOR, HS MODELS         0210001175           15         AERATOR, LAMINAR FLOW CONTROL, 1.2 GPM         0110001537           16         AERATOR INSTALLATION TOOL         0510000672           17         CHILLER REMOTE 115V/60HZ         HCR8           18         RFID BOARD PCBA         0210000745.6           19         COVER, CORNER, HS MODELS         0410000897           20         CLIP, PANEL ATTACHMENT, HS MODELS         0410000903           21         SCREW, 8-32 UNC X. 500, SST, PAN, T-20 TORX         0310000551           22         SCREW, 10-24 UNC X. 563, SST, BUTTON HEAD, T20 TORX         0310000540           23         BUBBLER HEAD, PCP, 1001 BOWL         5705           24         BUBBLER HEAD, PCP, 1107 AND 1109 FTN         5703M           25         BUTTON, PUSH, 5874, FLANGED         PBA6           27         VALVE REPAIR KIT         VRK5874           28         STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN		PANEL, LOWER, 304 SST, HI-LO CHILLED	0410000924
11         GRATE, 304 SST, HS MODELS         0410000895           12         SCREW, 8-32 UNC X. 375, SST, PAN, T-20 TORX         0310000550           13         FUSE, 10A-250VAC, SLOW BLOW, 5MM X. 20MM, GLASS         0210001120           14         PCBA, PROXIMITY SENSOR, HS MODELS         0210001175           15         AERATOR, LAMINAR FLOW CONTROL, 1.2 GPM         0110001537           16         AERATOR INSTALLATION TOOL         0510000672           17         CHILLER REMOTE 115V/60HZ         HCR8           18         RFID BOARD PCBA         0210000745.6           19         COVER, CORNER, HS MODELS         0410000897           20         CLIP, PANEL ATTACHMENT, HS MODELS         0410000903           21         SCREW, 8-32 UNC X. 500, SST, PAN, T-20 TORX         0310000551           22         SCREW, 10-24 UNC X. 563, SST, BUTTON HEAD, T20 TORX         0310000540           23         BUBBLER HEAD, PCP, 1107 AND 1109 FTN         5703M           25         BUTTON, PUSH, 5874, FLANGED W/ VALVE         5874PBF           26         BUTTON, PUSH, 5874, FLANGED W/ VALVE         5874PBF           26         BUTTON, PUSH, 5874, FLANGED PBA6         PBA6           27         VALVE REPAIR KIT         VRK5874           28         STRAINER, WASTE ASSEMBLY,	9	VALVE, SOLENOID, 3/8 QC, 120VAC	0110000827.4
12         SCREW, 8-32 UNC X .375, SST, PAN, T-20 TORX         0310000550           13         FUSE, 10A-250VAC, SLOW BLOW, 5MM X 20MM, GLASS         0210001120           14         PCBA, PROXIMITY SENSOR, HS MODELS         0210001175           15         AERATOR, LAMINAR FLOW CONTROL, 1.2 GPM         0110001537           16         AERATOR INSTALLATION TOOL         0510000672           17         CHILLER REMOTE 115V/60HZ         HCR8           18         RFID BOARD PCBA         0210000745.6           19         COVER, CORNER, HS MODELS         0410000897           20         CLIP, PANEL ATTACHMENT, HS MODELS         0410000903           21         SCREW, 8-32 UNC X. 500, SST, PAN, T-20 TORX         0310000551           22         SCREW, 10-24 UNC X. 563, SST, BUTTON HEAD, T20 TORX         0310000540           23         BUBBLER HEAD, PCP, 1001 BOWL         5705           24         BUBBLER HEAD, PCP, 1107 AND 1109 FTN         5703M           25         BUTTON, PUSH, 5874, FLANGED W/ VALVE         5874PBF           26         BUTTON, PUSH, 5874, FLANGED         PBA6           27         VALVE REPAIR KIT         VRK5874           28         STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN         6463           29         STRAINER, WASTE ASSEMBLY, 1	10	DRAIN BASIN, HS MODELS	0410000894
13         FUSE, 10A-250VAC, SLOW BLOW, 5MM X 20MM, GLASS         0210001120           14         PCBA, PROXIMITY SENSOR, HS MODELS         0210001175           15         AERATOR, LAMINAR FLOW CONTROL, 1.2 GPM         0110001537           16         AERATOR INSTALLATION TOOL         0510000672           17         CHILLER REMOTE 115V/60HZ         HCR8           18         RFID BOARD PCBA         0210000745.6           19         COVER, CORNER, HS MODELS         0410000897           20         CLIP, PANEL ATTACHMENT, HS MODELS         0410000903           21         SCREW, 8-32 UNC X. 500, SST, PAN, T-20 TORX         0310000551           22         SCREW, 10-24 UNC X. 563, SST, BUTTON HEAD, T20 TORX         0310000540           23         BUBBLER HEAD, PCP, 1001 BOWL         5705           24         BUBBLER HEAD, PCP, 1107 AND 1109 FTN         5703M           25         BUTTON, PUSH, 5874, FLANGED W/ VALVE         5874PBF           26         BUTTON, PUSH, 5874, FLANGED         PBA6           27         VALVE REPAIR KIT         VRK5874           28         STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN         6463           29         STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN         6462           30         PLATE, BOTTOM, 1107 FTN	11	GRATE, 304 SST, HS MODELS	0410000895
14         PCBA, PROXIMITY SENSOR, HS MODELS         0210001175           15         AERATOR, LAMINAR FLOW CONTROL, 1.2 GPM         0110001537           16         AERATOR INSTALLATION TOOL         0510000672           17         CHILLER REMOTE 115V/60HZ         HCR8           18         RFID BOARD PCBA         0210000745.6           19         COVER, CORNER, HS MODELS         0410000897           20         CLIP, PANEL ATTACHMENT, HS MODELS         0410000903           21         SCREW, 8-32 UNC X. 500, SST, PAN, T-20 TORX         0310000551           22         SCREW, 10-24 UNC X. 563, SST, BUTTON HEAD, T20 TORX         0310000540           23         BUBBLER HEAD, PCP, 1001 BOWL         5705           24         BUBBLER HEAD, PCP, 1107 AND 1109 FTN         5703M           25         BUTTON, PUSH, 5874, FLANGED W/ VALVE         5874PBF           26         BUTTON, PUSH, 5874, FLANGED PBA6         PBA6           27         VALVE REPAIR KIT         VRK5874           28         STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN         6463           29         STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN         6462           30         PLATE, BOTTOM, 1001 FTN         PBM1000           31         PLATE, BOTTOM, 1107 FTN         PBM1107	12	SCREW, 8-32 UNC X .375, SST, PAN, T-20 TORX	0310000550
15         AERATOR, LAMINAR FLOW CONTROL, 1.2 GPM         0110001537           16         AERATOR INSTALLATION TOOL         0510000672           17         CHILLER REMOTE 115V/60HZ         HCR8           18         RFID BOARD PCBA         0210000745.6           19         COVER, CORNER, HS MODELS         0410000897           20         CLIP, PANEL ATTACHMENT, HS MODELS         0410000903           21         SCREW, 8-32 UNC X. 500, SST, PAN, T-20 TORX         0310000540           22         SCREW, 10-24 UNC X. 563, SST, BUTTON HEAD, T20 TORX         0310000540           23         BUBBLER HEAD, PCP, 1001 BOWL         5705           24         BUBBLER HEAD, PCP, 1107 AND 1109 FTN         5703M           25         BUTTON, PUSH, 5874, FLANGED W/ VALVE         5874PBF           26         BUTTON, PUSH, 5874, FLANGED         PBA6           27         VALVE REPAIR KIT         VRK5874           28         STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN         6463           29         STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN         6462           30         PLATE, BOTTOM, 1001 FTN         PBM1000           31         PLATE, BOTTOM, 1107 FTN         PBM1107           32         PLATE, BOTTOM, 1105 FTN         PBM1105	13	FUSE, 10A-250VAC, SLOW BLOW, 5MM X 20MM, GLASS	0210001120
16         AERATOR INSTALLATION TOOL         0510000672           17         CHILLER REMOTE 115V/60HZ         HCR8           18         RFID BOARD PCBA         0210000745.6           19         COVER, CORNER, HS MODELS         0410000897           20         CLIP, PANEL ATTACHMENT, HS MODELS         0410000903           21         SCREW, 8-32 UNC X. 500, SST, PAN, T-20 TORX         0310000554           22         SCREW, 10-24 UNC X. 563, SST, BUTTON HEAD, T20 TORX         0310000540           23         BUBBLER HEAD, PCP, 1001 BOWL         5705           24         BUBBLER HEAD, PCP, 1107 AND 1109 FTN         5703M           25         BUTTON, PUSH, 5874, FLANGED W/ VALVE         5874PBF           26         BUTTON, PUSH, 5874, FLANGED         PBA6           27         VALVE REPAIR KIT         VRK5874           28         STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN         6463           29         STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN         6462           30         PLATE, BOTTOM, 1001 FTN         PBM1000           31         PLATE, BOTTOM, 1107 FTN         PBM1107           32         PLATE, BOTTOM, 1105 FTN         PBM1105	14	PCBA, PROXIMITY SENSOR, HS MODELS	0210001175
17         CHILLER REMOTE 115V/60HZ         HCR8           18         RFID BOARD PCBA         0210000745.6           19         COVER, CORNER, HS MODELS         0410000897           20         CLIP, PANEL ATTACHMENT, HS MODELS         0410000903           21         SCREW, 8-32 UNC X.500, SST, PAN, T-20 TORX         0310000551           22         SCREW, 10-24 UNC X.563, SST, BUTTON HEAD, T20 TORX         0310000540           23         BUBBLER HEAD, PCP, 1001 BOWL         5705           24         BUBBLER HEAD, PCP, 1107 AND 1109 FTN         5703M           25         BUTTON, PUSH, 5874, FLANGED W/ VALVE         5874PBF           26         BUTTON, PUSH, 5874, FLANGED         PBA6           27         VALVE REPAIR KIT         VRK5874           28         STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN         6463           29         STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN         6462           30         PLATE, BOTTOM, 1001 FTN         PBM1000           31         PLATE, BOTTOM, 1107 FTN         PBM1107           32         PLATE, BOTTOM, 1105 FTN         PBM1105	15	AERATOR, LAMINAR FLOW CONTROL, 1.2 GPM	0110001537
18         RFID BOARD PCBA         021000745.6           19         COVER, CORNER, HS MODELS         0410000897           20         CLIP, PANEL ATTACHMENT, HS MODELS         0410000903           21         SCREW, 8-32 UNC X.500, SST, PAN, T-20 TORX         0310000551           22         SCREW, 10-24 UNC X.563, SST, BUTTON HEAD, T20 TORX         0310000540           23         BUBBLER HEAD, PCP, 1001 BOWL         5705           24         BUBBLER HEAD, PCP, 1107 AND 1109 FTN         5703M           25         BUTTON, PUSH, 5874, FLANGED W/ VALVE         5874PBF           26         BUTTON, PUSH, 5874, FLANGED         PBA6           27         VALVE REPAIR KIT         VRK5874           28         STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN         6463           29         STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN         6462           30         PLATE, BOTTOM, 1001 FTN         PBM1000           31         PLATE, BOTTOM, 1107 FTN         PBM1107           32         PLATE, BOTTOM, 1109 FTN         PBM1109           33         PLATE, BOTTOM, 1105 FTN         PBM1105	16	AERATOR INSTALLATION TOOL	0510000672
19         COVER, CORNER, HS MODELS         0410000897           20         CLIP, PANEL ATTACHMENT, HS MODELS         0410000903           21         SCREW, 8-32 UNC X. 500, SST, PAN, T-20 TORX         0310000551           22         SCREW, 10-24 UNC X. 563, SST, BUTTON HEAD, T20 TORX         0310000540           23         BUBBLER HEAD, PCP, 1001 BOWL         5705           24         BUBBLER HEAD, PCP, 1107 AND 1109 FTN         5703M           25         BUTTON, PUSH, 5874, FLANGED W/ VALVE         5874PBF           26         BUTTON, PUSH, 5874, FLANGED         PBA6           27         VALVE REPAIR KIT         VRK5874           28         STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN         6463           29         STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN         6462           30         PLATE, BOTTOM, 1001 FTN         PBM1000           31         PLATE, BOTTOM, 1107 FTN         PBM1107           32         PLATE, BOTTOM, 1109 FTN         PBM1109           33         PLATE, BOTTOM, 1105 FTN         PBM1105		CHILLER REMOTE 115V/60HZ	HCR8
20         CLIP, PANEL ATTACHMENT, HS MODELS         0410000903           21         SCREW, 8-32 UNC X .500, SST, PAN, T-20 TORX         0310000551           22         SCREW, 10-24 UNC X .563, SST, BUTTON HEAD, T20 TORX         0310000540           23         BUBBLER HEAD, PCP, 1001 BOWL         5705           24         BUBBLER HEAD, PCP, 1107 AND 1109 FTN         5703M           25         BUTTON, PUSH, 5874, FLANGED W/ VALVE         5874PBF           26         BUTTON, PUSH, 5874, FLANGED         PBA6           27         VALVE REPAIR KIT         VRK5874           28         STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN         6463           29         STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN         6462           30         PLATE, BOTTOM, 1001 FTN         PBM1000           31         PLATE, BOTTOM, 1107 FTN         PBM1107           32         PLATE, BOTTOM, 1109 FTN         PBM1109           33         PLATE, BOTTOM, 1105 FTN         PBM1105	18	RFID BOARD PCBA	0210000745.6
21       SCREW, 8-32 UNC X .500, SST, PAN, T-20 TORX       0310000551         22       SCREW, 10-24 UNC X .563, SST, BUTTON HEAD, T20 TORX       0310000540         23       BUBBLER HEAD, PCP, 1001 BOWL       5705         24       BUBBLER HEAD, PCP, 1107 AND 1109 FTN       5703M         25       BUTTON, PUSH, 5874, FLANGED W/ VALVE       5874PBF         26       BUTTON, PUSH, 5874, FLANGED       PBA6         27       VALVE REPAIR KIT       VRK5874         28       STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN       6463         29       STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN       6462         30       PLATE, BOTTOM, 1001 FTN       PBM1000         31       PLATE, BOTTOM, 1107 FTN       PBM1107         32       PLATE, BOTTOM, 1109 FTN       PBM1109         33       PLATE, BOTTOM, 1105 FTN       PBM1105	19	COVER, CORNER, HS MODELS	0410000897
22       SCREW, 10-24 UNC X .563, SST, BUTTON HEAD, T20 TORX       0310000540         23       BUBBLER HEAD, PCP, 1001 BOWL       5705         24       BUBBLER HEAD, PCP, 1107 AND 1109 FTN       5703M         25       BUTTON, PUSH, 5874, FLANGED W/ VALVE       5874PBF         26       BUTTON, PUSH, 5874, FLANGED PBA6       PBA6         27       VALVE REPAIR KIT VRK5874         28       STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN       6463         29       STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN       6462         30       PLATE, BOTTOM, 1001 FTN       PBM1000         31       PLATE, BOTTOM, 1107 FTN       PBM1107         32       PLATE, BOTTOM, 1109 FTN       PBM1109         33       PLATE, BOTTOM, 1105 FTN       PBM1105			0410000903
23         BUBBLER HEAD, PCP, 1001 BOWL         5705           24         BUBBLER HEAD, PCP, 1107 AND 1109 FTN         5703M           25         BUTTON, PUSH, 5874, FLANGED W/ VALVE         5874PBF           26         BUTTON, PUSH, 5874, FLANGED         PBA6           27         VALVE REPAIR KIT         VRK5874           28         STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN         6463           29         STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN         6462           30         PLATE, BOTTOM, 1001 FTN         PBM1000           31         PLATE, BOTTOM, 1107 FTN         PBM1107           32         PLATE, BOTTOM, 1109 FTN         PBM1109           33         PLATE, BOTTOM, 1105 FTN         PBM1105	21	SCREW, 8-32 UNC X .500, SST, PAN, T-20 TORX	0310000551
24         BUBBLER HEAD, PCP, 1107 AND 1109 FTN         5703M           25         BUTTON, PUSH, 5874, FLANGED W/ VALVE         5874PBF           26         BUTTON, PUSH, 5874, FLANGED         PBA6           27         VALVE REPAIR KIT         VRK5874           28         STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN         6463           29         STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN         6462           30         PLATE, BOTTOM, 1001 FTN         PBM1000           31         PLATE, BOTTOM, 1107 FTN         PBM1107           32         PLATE, BOTTOM, 1109 FTN         PBM1109           33         PLATE, BOTTOM, 1105 FTN         PBM1105		SCREW, 10-24 UNC X .563, SST, BUTTON HEAD, T20 TORX	0310000540
25         BUTTON, PUSH, 5874, FLANGED W/VALVE         5874PBF           26         BUTTON, PUSH, 5874, FLANGED         PBA6           27         VALVE REPAIR KIT         VRK5874           28         STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN         6463           29         STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN         6462           30         PLATE, BOTTOM, 1001 FTN         PBM1000           31         PLATE, BOTTOM, 1107 FTN         PBM1107           32         PLATE, BOTTOM, 1109 FTN         PBM1109           33         PLATE, BOTTOM, 1105 FTN         PBM1105		BUBBLER HEAD, PCP, 1001 BOWL	5705
26         BUTTON, PUSH, 5874, FLANGED         PBA6           27         VALVE REPAIR KIT         VRK5874           28         STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN         6463           29         STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN         6462           30         PLATE, BOTTOM, 1001 FTN         PBM1000           31         PLATE, BOTTOM, 1107 FTN         PBM1107           32         PLATE, BOTTOM, 1109 FTN         PBM1109           33         PLATE, BOTTOM, 1105 FTN         PBM1105	24	BUBBLER HEAD, PCP, 1107 AND 1109 FTN	5703M
27         VÁLVE RÉPAIR KIT         VRK5874           28         STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN         6463           29         STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN         6462           30         PLATE, BOTTOM, 1001 FTN         PBM1000           31         PLATE, BOTTOM, 1107 FTN         PBM1107           32         PLATE, BOTTOM, 1109 FTN         PBM1109           33         PLATE, BOTTOM, 1105 FTN         PBM1105	25	BUTTON, PUSH, 5874, FLANGED W/ VALVE	5874PBF
28       STRAINER, WASTE ASSEMBLY, SCP OR PCP, 1001 FTN       6463         29       STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN       6462         30       PLATE, BOTTOM, 1001 FTN       PBM1000         31       PLATE, BOTTOM, 1107 FTN       PBM1107         32       PLATE, BOTTOM, 1109 FTN       PBM1109         33       PLATE, BOTTOM, 1105 FTN       PBM1105		BUTTON, PUSH, 5874, FLANGED	PBA6
29         STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN         6462           30         PLATE, BOTTOM, 1001 FTN         PBM1000           31         PLATE, BOTTOM, 1107 FTN         PBM1107           32         PLATE, BOTTOM, 1109 FTN         PBM1109           33         PLATE, BOTTOM, 1105 FTN         PBM1105		VALVE REPAIR KIT	VRK5874
30         PLATE, BOTTOM, 1001 FTN         PBM1000           31         PLATE, BOTTOM, 1107 FTN         PBM1107           32         PLATE, BOTTOM, 1109 FTN         PBM1109           33         PLATE, BOTTOM, 1105 FTN         PBM1105	28		6463
31         PLATE, BOTTOM, 1107 FTN         PBM1107           32         PLATE, BOTTOM, 1109 FTN         PBM1109           33         PLATE, BOTTOM, 1105 FTN         PBM1105		STRAINER, WASTE ASSEMBLY, 1107 AND 1109 FTN	6462
32         PLATE, BOTTOM, 1109 FTN         PBM1109           33         PLATE, BOTTOM, 1105 FTN         PBM1105			PBM1000
33 PLATE, BOTTOM, 1105 FTN PBM1105		PLATE, BOTTOM, 1107 FTN	
33         PLATE, BOTTOM, 1105 FTN         PBM1105           34         DRIVER, NOZZLE, .25 HEX         0002082253		PLATE, BOTTOM, 1109 FTN	
34 DRIVER, NOZZLE, .25 HEX 0002082253		PLATE, BOTTOM, 1105 FTN	PBM1105
	34	DRIVER, NOZZLE, .25 HEX	0002082253







Haws Since 1906

SCALE: 1:20 DRAWING TYPE:

1455 KLEPPE LANE SPARKS, NEVADA 89431 (775) 359-4712 FAX (775) 359-7424 E-MAIL: HAWS@HAWSCO.COM WEBSITE: WWW.HAWSCO.COM

WHEN ORDERING PARTS, PLEASE SPECIFY PART NUMBER

REV. ECN: BY: 6000 DHP
DATE: CHK'D. 12/15/22 JU
DESCRIPTION: DATE: 08/02/24 MODEL(S) 1XXXHSA.8, DUAL FOUNTAIN MODELS, CHILLED

0510002201

© 2024 Haws Corporation - All Rights Reserved.



1455 KLEPPE LANE SPARKS, NEVADA 89431 (775) 359-4712 FAX (775) 359-7424 E-MAIL: HAWS@HAWSCO.COM WEBSITE: WWW.HAWSCO.COM

WHEN ORDERING PARTS, PLEASE SPECIFY PART NUMBER

SCALE: 1:20 DRAWING TYPE:

0510002201

REVISION

1

SHEET 2 05 2